ATC Service Technician Certification Program:

Door closed limit switch:

On top of the pedestal towards the rear of the cab, there is the door closed limit switch. This switch detects when the conversion doors are completely closed and completes the circuit to actuate the front door latch and allow the vehicle to be put in gear.

Small adjustments can be made to the contact bolt on the door to ensure proper grounding. (One full turn out of the bolt can cause the front latch to engage too early which can cause damage to the front of the doors).

Remember to tighten the nut to ensure the contact bolt doesn't back itself out and cause the latch to engage too early. Small adjustments are recommended. Only make adjustments to the contact bolt on the doors.

ATC CONVERSIONS MOBILITY