DOOR MAGNET REPLACEMENT INSTRUCTIONS

The door magnet that came with your ATC conversion has been discontinued by the manufacturer. This kit will allow you to update the magnet to the newer style.

In your replacement kit you will find the adaptor bracket, which will bolt in place of the OEM magnet that needs replaced. This will require the two (2) M6x1 button head screws included with your kit.

Use these to attach the adaptor plate to the old mounting bracket. The screws will protrude through the old mounting bracket and will need to be cut off flush with the mounting plate to allow the plate to sit flush when installed in the vehicle.

The New Magnet will be installed onto the adaptor/bracket assembly using four (4) M6x1 socket head screws.

NOTE: the wiring of the old Magnet before removal. The **yellow** and **red** wires on the new magnet should be connected where the **red** and **black** wires were from the old magnet. The **black** and **green** wires on the new magnet will replace the **green** and **orange** wires on the old magnet.

Install the magnet/bracket assembly back onto the truck, taking care to make sure that none of the wiring is getting pinched.

ATC CONVERSIONS
MOBILITY